

Airmaster Wall Cover



Figure 1: Wall cover seen from below (left) and the front (right)

The cover is designed as a fixed shield for AM 900 when intake and exhaust air are closely located. The cover protects against external short circuits, by separating intake in the bottom of the cover and exhaust by the vertical grille in the front.

The cover can be fixed with screws or nails.

Material and finish

- Galvanized Steel
- Standard finish: powder-coated, RAL 7037

Maintenance

The external parts should be wiped with a damp cloth. The cover must be inspected regularly and objects such as leaves must be removed.

The duct behind the cover must be cleaned regularly. To gain access to the ducts you must unmount the cover.

Technical Data

	Inlet	Exhaust
Free Area (A_f) [m ²]	0,0408	0,0262

Tabel 1: Free Area for Wall Cover

AIRMASTER




Figure 2: Wall cover dimensional drawing